

RetroSpy Vision Support Matrix

X = Supported with correct Vision cable

Y = Supported with no additional cable/hardware required

Z = Supported, but adapters required

| Consoles/Controllers | | Flex | Analog | CDi | CV | ADB | USB Lite (Coming Soon) | Original (Discontinued) | Dream (Discontinued) | USB (Discontinued) |
|---------------------------|----------------------|---------|--------|------|------|------|---------------------------|----------------------------|-------------------------|-----------------------|
| Introduced Controller Lag | | None | None | None | None | None | None | None | None | ~3 Frames |
| Amstrad GX4000 | | X | X | | | | | X | | |
| Atari 2600 | Joystick | X | X | | | | | X | | |
| | Driving Controller | X | X | | | | | X | | |
| | Keyboard Controller | Partial | | | | | | X | | |
| | Booster Grip | X | X | | | | | X | | |
| | Paddles | | X | | | | | | | |
| Atari 5200 | | | X | | | | | | | |
| Atari 7800 | | X | X | | | | | X | | |
| Atari Jaguar | | X | X | | | | | X | | |
| Atari VCS | | | | | | | Y | | | Y |
| Bandai/Apple Pippin | | | | | | Y | | | | |
| Coleco ColecoVision | | | | | Y | | | | | |
| Commodore CDTV | Mouse | X | | | | | | X | | |
| | Keyboard | X | | | | | | X | | |
| | Wireless Remote | | | Y | | | | | | |
| Amiga CD32 | Mouse | X | | | | | | X | | |
| | Keyboard | X | | | | | | X | | |
| | 1-button Joysticks | X | X | | | | | X | | |
| | 4-button Controllers | X | | | | | | | | |
| | Analog Joystick | | X | | | | | | | |
| C64 Mini | | | | | | | Y | | | Y |
| The A500 Mini | | | | | | | Y | | | Y |
| Evercade Vs | | | | | | | Y | | | Y |
| FM Towns Marty | Controller | X | X | | | | | X | | |
| | Mouse | X | | | | | | | | |
| | Keyboard | X | | | | | | | | |
| Mattel Intellivision | | X | X | | | | | X | | |

| Consoles/Controllers | | Flex | Analog | CDi | CV | ADB | USB Lite (Coming Soon) | Original (Discontinued) | Dream (Discontinued) | USB (Discontinued) |
|------------------------------------|--------------------------|----------|--------|-----|----|-----|---------------------------|----------------------------|-------------------------|-----------------------|
| Odyssey 2 | | X | X | | | | | X | | |
| Microsoft Xbox | | | | | | | Z | | | Z |
| Microsoft Xbox 360 | | | | | | | Y | | | Y |
| NEC PC Engine/ TG-16 & Supergrafx | | X | X | | | | | X | | |
| NEC PC-FX | | X | X | | | | | X | | |
| NEC Turbo-Grafx-16 Mini | | | | | | | Y | | | Y |
| NES | Controller | X | X | | | | | X | | |
| | Power Pad | X | X | | | | | X | | |
| | Power Glove | X | X | | | | | X | | |
| SNES | | X | X | | | | | X | | |
| Virtual Boy | | X | X | | | | | X | | |
| N64 | | Advanced | Basic | | | | | Basic | Advanced | |
| GBA Consolizer | | X | X | | | | | X | | |
| Nintendo Gamecube | | Advanced | Basic | | | | | Basic | Advanced | |
| Nintendo Wii Extension Controllers | | X | | | | | | | X | |
| Nintendo Switch | | | | | | | Y | | | Y |
| NES Classic | | X | | | | | | | X | |
| SNES Classic | | X | | | | | | | X | |
| 3DO | | X | X | | | | | X | | |
| Phillips CDi | | | | Y | | | | | | |
| Sega Master System | Controller | X | X | | | | | X | | |
| | Paddle | X | X | | | | | X | | |
| | Sports Pad | X | X | | | | | X | | |
| Sega Genesis | 3 or 6 button Controller | X | X | | | | | X | | |
| | Mega Mouse | X | X | | | | | X | | |
| Sega Saturn | Digital Controller | X | X | | | | | X | | |
| | 3D Control Pad | X | X | | | | | X | | |
| | Keyboard | X | X | | | | | X | | |
| | Shuttle Mouse | X | X | | | | | X | | |

